




Step 1




Masonry Walls or Cement Walls



Stud Walls




Step 2



注意事項 Note Hinweis Remarque
Nota 注意事項 Nota Nota
Zaznaczaję Примечание OBS

Step 3


1
2




注意事項 Note Hinweis Remarque
Nota 注意事項 Nota Nota
Zaznaczaję Примечание OBS

中文 選擇顯示器的視角為0°時
EN When the display view is at 0°
DE Wenn der Winkel des anzeigen 0° ist
FR Lorsque l'angle du afficher est 0°
ES Si ve el monitor a 0°
日本語 ディスプレイ視角が0°を選択する場合
IT Quando la visualizzazione della display è a 0°
PT Quando a vista da exibição estiver em 0°
PL Kiedy opinia pokaz jest przy 0°
RU Когда взгляд дисплей на 0°
SV När Visa-vyn är 0°

中文 選擇顯示器的視角為5°/10°/13°/15°時
EN When the display viewing angle 5°/10°/13°/15° is selected
DE Wenn ein Blickwinkel von 5°/10°/13°/15° gewünscht wird
FR Lorsqu'un angle de 5°/10°/13°/15° est utilisé
ES Si desea seleccionar ángulos de 5°/10°/13°/15°
日本語 ディスプレイ視角が5°/10°/13°/15°を選択する場合
IT Quando viene selezionato un angolo di visualizzazione di 5°/10°/13°/15°
PT Quando o ângulo 5°/10°/13°/15° da visão da exibição for seleccionado
PL Kiedy opinia oglądający kąt 55°/10°/13°/15° jest doberany
RU Когда угол 5°/10°/13°/15° viewing дисплей выбран
SV När Visa 5°/10°/13°/15° är vald




3




注意事項 Note Hinweis Remarque
Nota 注意事項 Nota Nota
Zaznaczaję Примечание OBS

Step 4




Step 5



注意事項 Note Hinweis Remarque
Nota 注意事項 Nota Nota
Zaznaczaję Примечание OBS

Step 6




注意事項 Note Hinweis Remarque
Nota 注意事項 Nota Nota
Zaznaczaję Примечание OBS

Torque adjust



Tilt adjust: 30° Tilt Range



15° back

15° forward