




Quick Start Guide

SE3201 LCD Display


SE3201 Eprel registration number: 2788106




①








②




③



④



- (Menu) 1
- (Up) ▲
- (Down) ▼
- (Source) 2
- (Power) ⏻



Do not dispose of your product or battery with your household waste.
For most up-to-date recycling information, please go to www.agneovo.com/support/recycling
Werfen Sie das Gerät oder die Batterie nicht in den Hausmüll.
Die aktuellsten Informationen zum Recycling finden Sie unter www.agneovo.com/support/recycling

